




COLD PACKAGE PURE LEAD BATTERY CHARGING

CHARGE: STEP 1

CHECK BATTERY STATUS AT THE TOP OF THE HMI



CHARGE: STEP 2

CHARGE WHEN YOU REACH 4 BARS

CHARGE: STEP 3

SWITCH MACHINE OFF, LIFT BATTERY COVER, INSERT CABLE INTO AN OUTLET AND CHARGE TO 100%. DO NOT PLACE CABLE ON TOP OF BATTERIES

ANNUALLY

TEST ALL CONNECTIONS (CABLES, CONTACTS, OUTLETS)
REMOVE DUST FROM THE CHARGER

STORAGE

STORE IN FULLY CHARGED CONDITION. DISCONNECT BATTERY FROM ROBOT BEFORE STORAGE. FULLY RECHARGE EVERY 2 MONTHS

